

Special adhesive tape installation

Article No.: 400066



See our videos on our homepage under Service/Downloads for installation of T-STRIPE: <https://www.t-stripe.com/pages/service/downloads/>

Important: For installation, the window pane must be at least 20°C warm! Please heat up the window with a radiant heater if necessary. Please ensure clean surfaces during processing, which must be free of e.g. grease, oil or silicone films and without dirt particles. The final adhesive force at 20 °C is reached after approx. 72 h. You can switch on T-STRIPE immediately after installation.

Tip: If you wait an hour, the adhesive tape already adheres and the protective film is easier to remove. Pull it! By using the primer (Art. No.: 400960) on the glass pane, you increase the strength of the connection.



If you install the heating element directly on the window pane:

1. Clean both the outermost edge of the window pane and the heating element with the special cleaning agent (Art. No. 400910). The special cleaner must not come into contact with the rubber profile of the window. After cleaning, do not touch the window again so that the adhesive tape can adhere.
2. Now apply the primer thinly to the window as described in the "Silan" primer instructions.
3. Start now to stick the adhesive tape on the window pane. Remove the red protective foil. Use a roller to press the tape firmly along its entire length.
4. After you have completely attached the adhesive tape to the window, remove the red protective foil from the window.
Tip: If you wait an hour, the adhesive tape already sticks and the protective film is easier to remove.
5. Now press the - cleaned with the special cleaner! - Place the heating element on the adhesive tape.
6. Now press the heating element - which has been cleaned with the special cleaner - onto the adhesive tape.

If you install the heating element in the design aluminium bar (see design aluminium bar instructions):

If you are installing aluminium bars in anthracite, natural or white, then it is necessary to remove the surface and to clean it carefully afterwards.

Following applies to all aluminium bars,

Clean the aluminium strip with the special cleaner (Art. No.: 400066) - stick the adhesive tape to the aluminium bar. Do not remove the red protective foil yet. Press it firmly along the entire length.

Clean the outermost edge of the window pane with the special cleaner. The special cleaner must not come into contact with the rubber profile of the window. After cleaning, don't touch the pane, so the tape can stick.

Now remove the protective foil and press the aluminium bar firmly along the entire length of the window pane. (directly on the glass).

For all installation instructions see www.t-stripe.com menu point "Service" under "Downloads".



Tel.: +43 1 997 17 49
Fax: +43 1 997 17 49 / 31
Email: info@t-stripe.com
Website: www.t-stripe.com



Download info, videos and installation instructions.